## Hi, lam your instruction manual



	REF	QTY	REF	QTY	REF	QTY
Carton 1/4	A	4PCS		4PCS	J	4PCS
	K	49PCS		1PC	M	25PCS
	N	4PCS	0	24PCS	P	52PCS
	Q	104PCS	R	12PCS	S	27PCS
	T	1PC	U	1PC	V	1PC
	(W)	16PCS	X	1PC	Y	2PCS
	User Manual	1SET				
Carton 2/4	B <sub>1</sub>	1PC	B2	1PC	C	2PCS
	G	1PC	H	1PC		
Carton 3/4	D	13PCS				
Carton 4/4	D	12PCS				


REF	PICTURE	QTY
A		4PCS
<b>B1</b>		1PC
<b>B2</b>		1PC
<u>C</u>		2PCS
D		25PCS
G		1PC
$\bigoplus$		1PC


REF	PICTURE	QTY	REF	PICTURE	QTY
		4PCS	R	5.5x19mm	12PCS
<u></u>		4PCS	S		27PCS
K		49PCS	$\Box$		1PC
		1PC	٥	M6x45	1PC
(No. 1)		25PCS	$\bigcirc$		1PC
N		4PCS	W		16PCS
0		24PCS	X		1PC
P	M5x10mm	52PCS	Ŷ		2PCS
Q	4.2x18mm	104PCS			


## Warning


In snow season or in case of snow forecast open up your shutters in vertical position to avoid any damaging on your pergola.


What you need?































## Make the shutter as vertical.

